

Building Material



Feature:

1. [\[Link\]](#)
2. [\[Link\]](#)
3. [\[Link\]](#)
4. [\[Link\]](#)
5. [\[Link\]](#)

Specification

PU (Polyurethane) material is used for decorative elements. It is durable, weather-resistant, and easy to maintain. The material is available in various colors and finishes. The material is made of high-quality PU foam. The material is easy to install and remove. The material is suitable for indoor and outdoor use. The material is available in various sizes and shapes. The material is made of high-quality MDF. The material is easy to install and remove.

1	Material	High Quality PU (Polyurethane)
2	MOQ	100 pcs
3	Color	White, Grey, Brown
4	Finish	Matte, Glossy
5	Material	PU Foam
6	Lead Time	T / T
7	Weight	Lightweight and easy to handle
8	Installation	Easy to install and remove
9	Usage	Indoor and outdoor decoration
10	Lead Time	40 days
11	Material	High Quality MDF

Products applications



Products applications



Our company

Finehope 2002 年 100 年 41 年 32 年, 7000 年 1000 年.





Quality control



I. Quality Management






- ◆ Through the continuous push, maintenance and periodic review for the quality management system of ISO9001, ISO/TS 16949, to ensure the system works sufficiently, appropriately and effectively.
- ◆ Five core tools of ISO/TS 16949 : APQP, FMEA, MSA, SPC and PPAP. The effective use of these five core tools can make our quality control and overall management level improved greatly, finally to meet the requirements of customer.

II. Material Research and Develop



◆ Under a professional PU material R&D team, the products that has been put into production include MDI, TDI, HDI and PPDI etc polyether and polyester system formula, which covering all PU systems formula.

Certifications



1. Finehope 0000 00 000 0000?

1. 00 00 00, 00 00, 00 000 000
2. 00 00000 00 00 000, 0000 00 0000 00
3. Finehope 00 000 000 00 0 00 00 0 0000 00 00 00 000 000 00 000 000 0000.
4. 0 00 00 00.
5. 000 0000 0000 000000 00000.
6. pu 000 000 000 000000 000 00000.
7. Finehope 00 0 00 00 00 00 0 00 0000 00 000 0000 00000.

2. Finehope 00 00 000 0000 00000?

1. 00 00 : 00 00 00 00 (APQP).
2. Finehope 00 00000 000 0000 000 00000.
3. 00 000 000 00 00 00 00 0000 0000.
4. 00 00 0 000 00000 00, 00 0 00 00 00.
5. 00 00 000 0 00 000 00000 00000 00 00000 00000.

3. Finehope 00 0 00 00 00 0000 00000?

1. 00000 000 00 00 000 0000.
2. 00 00 00
3. 00 0 00 00 0 00 000 000.
4. 00 000000 00 000 00.

4. 0 Finehope 00000?

1. Finehope 00000 00 00000 pu 00 00000, 00 R & D 0, 00 PU 00 00, 00 0000 00 0 00 0 00 00 0000. 0000 CAT, FIAT, TVH, GGP 0 00 00 000 12 0 00 0000 000 00000. 0000 00000 R & D 0000 0000 00 000000.

